

MET-211 Lab 3 Group 7

Properties and Stress Concentrations

Brooke Baker, Lukas DiBeneditto, Austin Kramer

Fall 2018

Purdue Polytechnic New Albany



Polytechnic Institute



Lab 3: Goals of the Lab

Properties and Stress Concentrations



Specimen in Universal Testing Machine (UTM)

1. Determine how much **variation** exists in the Elastic Modulus of a selection of steel samples due to alloy and geometry.
2. Determine the accuracy of **failure predictions** due to stress concentration.
3. Present the **results** of your investigation in the laboratory to the class so the data can be combined with others and compared.

1. Variation: Elastic Modulus

Determine how much variation exists in the Elastic Modulus of a selection of steel samples due to alloy and geometry.

Elastic Modulus (Young's Modulus) (*Stiffness of a material*)

The modulus of elasticity, E , is a measure of the stiffness of a material determined by the slope of the straight-line portion of the stress-strain curve. It is the ratio of the change of stress to the corresponding change in strain. [textbook, p. 59]

$$E = \frac{\text{stress}}{\text{strain}} = \frac{\sigma}{\epsilon}$$

1. Variation: Typical Stress-Strain Curve

Determine how much variation exists in the Elastic Modulus of a selection of steel samples due to alloy and geometry.

Typical Stress-Strain Curve: Low Carbon Steel

A. Proportional Limit:

Straight line indicates stress is proportional to strain.

B. Elastic Limit:

Material will return to original size and shape if load is removed. At higher stresses material is permanently deformed.


C. Yield Point: 248 MPa (36,000 psi)

Stress at which a noticeable elongation of the sample occurs with no apparent increase in load.

D. Tensile Strength: 365 MPa (54,000 psi)

Highest Value of apparent stress.

[textbook, pp. 56-57]



Source: Typical stress-strain curve for steel. [textbook, p. 57]

1. Variation: Specimen Material Properties

Determine how much variation exists in the Elastic Modulus of a selection of steel samples due to alloy and geometry.

AISI 12L14 Carbon Steel (UNS G12144) (Low Carbon Steel)

AISI (American Iron and Steel Institute)

| | Metric | English |
|---------------------|------------------------|--------------------------|
| Density | 7.87 g/cm ³ | 0.284 lb/in ³ |
| Elastic modulus | 190-210 GPa | 27557-30458 ksi |
| Yield Point | 415 MPa | 60200 psi |
| Tensile strength | 540 MPa | 78300 psi |
| Elongation at break | 10% | 10% |
| Reduction of area | 35% | 35% |
| Poisson's ratio | 0.27-0.30 | 0.27-0.30 |

Source: [aisi]

Material type verified with a Olympus X DELTA Professional Handheld XRF Analyzer

X-Ray Diffraction (XRD) is a laboratory-based technique commonly used for identification of crystalline materials and analysis of unit cell dimensions. [xrd]




Source: [delta]

1. Variation: Typical vs. AISI 12L14

Determine how much variation exists in the Elastic Modulus of a selection of steel samples due to alloy and geometry.

| | Typical Carbon Steel | | AISI 12L14 Carbon Steel | |
|---------------------|----------------------|------------|-------------------------|-------------------|
| | Metric | English | Metric | English |
| Elastic modulus | 207 GPa | 30,000 ksi | 190-210 GPa | 27,557-30,458 ksi |
| Yield Point | 248 MPa | 36,000 psi | 415 MPa | 60,200 psi |
| Tensile strength | 365 MPa | 54,000 psi | 540 MPa | 78,300 psi |
| Elongation at break | 9-36% | 9-36% | 10% | 10% |
| Poisson's ratio | 0.29 | 0.29 | 0.27-0.30 | 0.27-0.30 |

Typical test specimen geometry example.



1. Variation: Procedure Photo(s)

Scoring test specimens 25.4 mm (1 in) from center both sides for Extensometer.



1. Variation: Procedure Photo(s)

Marking test specimens (left for extensometer), (right for center punch).




1. Variation: Procedure Photo(s)

Center marked (left) for drilling to correct holes not in center (right).



1. Variation: Procedure Photo(s)

Reaming out holes (left) and 6 test specimens (right).




1. Variation: Procedure Photo(s)

Universal Testing Machine (UTM) set to low speed, speed dial constant for testing.



1. Variation: Procedure Photo(s)

Test to prevent slippage of test specimen (left), and specimen operator view (right).



2. Failure Predictions: Measurements

Determine the accuracy of failure predictions due to stress concentration.

Before: Necked Down Section Length (mm): 50.12

Before: Cross-Section Width (mm): 12.75

Before: Thickness (mm): 1.44

Before: Hole Diameter (mm): 5.06

Before: Overall Length (mm): 203.2

After: Overall Length No Holes (mm): 221.19

After: Overall Length With Holes (mm): 207.96

After: Necked Down Section Length No Holes (mm): 59.56

After: Necked Down Section Length With Holes (mm): 53.38

(Before - After) Overall Difference (mm): 13.23

| Sample # | Necked Down Section Length (Before)(mm) | | | | Cross-Section Width (mm) | | | | Thickness (mm) | | | |
|----------|---|-------|-------|---------|--------------------------|-------|-------|---------|----------------|------|------|---------|
| | 1 | 2 | 3 | Average | 1 | 2 | 3 | Average | 1 | 2 | 3 | Average |
| 1 | 50.74 | 49.59 | 50.27 | 50.2 | 12.79 | 12.74 | 12.76 | 12.76 | 1.46 | 1.54 | 1.4 | 1.47 |
| 2 | 49.48 | 49.72 | 49.54 | 49.58 | 12.76 | 12.74 | 12.75 | 12.75 | 1.44 | 1.5 | 1.47 | 1.47 |
| 3 | 50.05 | 50.24 | 49.64 | 49.98 | 12.71 | 12.76 | 12.75 | 12.74 | 1.44 | 1.45 | 1.46 | 1.45 |
| 4 | 51.28 | 49.3 | 49.68 | 50.09 | 12.71 | 12.73 | 12.74 | 12.73 | 1.44 | 1.47 | 1.45 | 1.45 |
| 5 | 50.89 | 49.98 | 50.69 | 50.52 | 12.75 | 12.74 | 12.76 | 12.75 | 1.44 | 1.44 | 1.45 | 1.44 |
| 6 | 50.13 | 50.22 | 50.31 | 50.22 | 12.72 | 12.75 | 12.76 | 12.74 | 1.43 | 1.42 | 1.42 | 1.42 |

| Sample # | Hole Diameter (mm) | | | | Necked Down Section Length (After)(mm) | | | | W/ Hole | Overall Length | Overall Length (After)(mm) |
|----------|--------------------|------|------|---------|--|-------|-------|---------|---------|----------------|----------------------------|
| | 1 | 2 | 3 | Average | 1 | 2 | 3 | Average | | | |
| 1 | None | None | None | None | 66.12 | 66.38 | 65.56 | 66.02 | No | 203.2 mm | 220.66 |
| 2 | None | None | None | None | 66.5 | 66.81 | 66.29 | 66.53 | No | 203.2 mm | 222.25 |
| 3 | None | None | None | None | 66.2 | 65.97 | 66.21 | 66.13 | No | 203.2 mm | 220.66 |
| 4 | 5.02 | 5.08 | 5.07 | 5.06 | 53.08 | 53.38 | 53.5 | 53.32 | Yes | 203.2 mm | 206.38 |
| 5 | 5.01 | 5.07 | 5.05 | 5.04 | 53.8 | 53.42 | 53.38 | 53.53 | Yes | 203.2 mm | 207.96 |
| 6 | 5.08 | 5.06 | 5.07 | 5.07 | 53.75 | 53.06 | 53.05 | 53.29 | Yes | 203.2 mm | 209.55 |

2. Failure Predictions: Calculations

Determine the accuracy of failure predictions due to stress concentration.

| | Width (W) (mm) | Thickness (T) (mm) | Cross Sectional Area (W x T) (mm ²) | L ₀ = (mm) | L _f = (mm) | Percent Elongation = $((L_f - L_0)/L_0) \times 100\%$ |
|----------------------|---------------------|-----------------------|--|--------------------------|--------------------------|--|
| Before No Holes | 12.75 | 1.44 | 18.36 | 50.12 | | |
| After No Holes | | | | | 59.56 | 15.84% |
| Before With Holes | 12.75-5.06 =7.69 | 1.44 | 11.07 | 50.12 | | |
| After With Holes | | | | | 53.38 | 6.11% |

2. Failure Predictions: Ideal

- The specimen should reach the yield point around as per the textbook based upon the material 248 MPa.

3. Results: Results Photo(s)

Specimens with smaller cross-sectional area elongate less and exhibit greater stress



3. Results: Typ., Spec., Predicted, Actual


Present the results of your investigation in the laboratory to the class so the data can be combined with others and compared.

| | Typical Carbon Steel | AISI 12L14 Carbon Steel | Predicted (Ideal) | Actual Results No Holes | Actual Results With Holes |
|---------------------|----------------------|-------------------------|-------------------|-------------------------|---------------------------|
| | Metric | Metric | Metric | Metric | Metric |
| Elastic modulus | 207 GPa | 190-210 GPa | 190-210 GPa | 290 GPa | 277 GPa |
| Yield Point | 248 MPa | 415 MPa | 415 MPa | 247 MPa | 243 MPa |
| Tensile strength | 365 MPa | 540 MPa | 540 MPa | 270 MPa | 290 MPa |
| Elongation at break | 9-36% | 10% | 10% | 31.5% | 6.4 MPa |
| Poisson's ratio | 0.29 | 0.27-0.30 | 0.27-0.30 | 1.1 | 0.18 |


3. Results: Graph(s)

Stress vs Strain Graph Sample No Hole and With Holes

No Holes: Stress (MPa) vs. Strain (mm/mm)




With Holes: Stress (MPa) vs. Strain (mm/mm)



3. Results: Graph(s) Combined Data

Stress vs Strain Graph Sample with and without Hole

No Holes and With Holes Stress vs Strain Comparison



3. Results: Things we could do differently

- Start earlier
- Provide information to Professor Sisk to review
- Measure Cross Sectional Area after (however this is open to considerable measurement error)

References

[textbook] Mott, Robert L. Applied strength of materials. Upper Saddle River, N.J: Pearson/Prentice Hall, 2008. Print.

[aisi] AISI 12L14 Carbon Steel (UNS G12144)
https://www_azom_com/article.aspx?ArticleID=6604

[wikipedia-tensile-testing] Tensile testing - Wikipedia
https://en.wikipedia.org/wiki/Tensile_testing

[delta] DELTA Professional Handheld XRF Analyzer
<https://www.olympus-ims.com/en/xrf-xrd/delta-handheld/delta-prof/>

[xrd] Definition: X-Ray Diffraction (XRD) | Open Energy Information
[https://openei.org/wiki/Definition:X-Ray_Diffraction_\(XRD\)](https://openei.org/wiki/Definition:X-Ray_Diffraction_(XRD))

Brooke Baker

Undergraduate

MET

baker504@purdue.edu

Lukas DiBeneditto

Undergraduate

MET

lukas@dibeneditto.com

Austin Kramer

Undergraduate

MET

austinmileskramer@gmail.com

Purdue Polytechnic Institute

polytechnic.purdue.edu

/ TechPurdue

